

# Cabinet for fixed gamma monitoring station



## Description

This optional unit is suited for the fixed gamma monitoring stations used for environmental monitoring. When the GAMON-S or GAMON-D is installed on a fixed stainless steel stand mounted on the ground or a wall some optionals can be included.

The power supply can be provided by 110/230 V or solar panel. Several option of UPS batteries allows for uninterrupted operation (6h, 24h, 48h, 72h).

I

In addition to the ethernet connection, optional communication interfaces can be added: (Wi-Fi, cellular (LTE), etc.)

Everything is installed in a stainless steel electrical cabinet including electrical protection. The robust stainless steel allow for installation in outdoor harsh environments ensuring a long life time of the system.

## Ordering Options

Code	Description	
WAGAMELCABAA	GAMON ELECTRICAL CABINET WITH UPS (12V, 3400mAh)	
WAGAMELCABAB	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (1 BATT)	RoHS
WAGAMELCABAC	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (2 BATT)	RoHS
WAGAMELCABAD	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (3 BATT)	RoHS
WAGAMELCABAE	GAMON ELECTRICAL CABINET FOR SOLAR PANEL	RoHS
WAGAMELCABLA	GAMON ELECTRICAL CABINET WITH UPS (12V, 3400mAh) AND LTE MODULE	RoHS
WAGAMELCABLB	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (1 BATT ) AND LTE MODULE	RoHS
WAGAMELCABLC	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (2 BATT ) AND LTE MODULE	RoHS
WAGAMELCABLD	GAMON ELECTRICAL CABINET WITH UPS LIFEPO4 (3 BATT ) AND LTE MODULE	RoHS
WAGAMELCABLE	GAMON ELECTRICAL CABINET WITH LTE MODULE FOR SOLAR PANEL	RoHS

## Related Products

### GAMON-S



Gamma Radiation Spectroscopy System for Real-Time Radiation Monitor

---

### GAMON-D



Gamma Dose Rate Monitoring System for Real-Time Radiation Monitor

---

**This document, or parts thereof, may not be reproduced in any form or by any means without written permission from Caen S.p.A. Although every effort has been made to ensure the accuracy of information presented in this catalog, Caen S.p.A reserves the right to modify its products specifications without giving any notice; for up to date information please visit [www.caen.it](http://www.caen.it) © Caen S.p.A - 2024**

**CAEN S.p.A.**

Via Vetraia 11  
55049 - Viareggio  
Italy

**Phone +39.0584.388.398**

**Fax +39.0584.388.959**

**info@caen.it**

**www.caen.it**

**CAEN GmbH**

Brunnenweg 9  
64331 Weiterstadt, Germany

**Phone +49 (0)212.254.4077**

**Mobile +49 (0)151.16.548.484**

**info@caen-de.com**

**www.caen-de.com**

**CAEN Technologies, Inc.**

1 Edgewater Street - Suite 101  
Staten Island, NY 10305  
USA

**Phone +1.718.981.0401**

**Fax +1.718.556.9185**

**info@caentechnologies.com**

**www.caentechnologies.com**

**CAENspa India Private Limited**

B205, BLDG42, B Wing,  
Azad Nagar Sangam CHS,  
Mhada Layout, Azad Nagar, Andheri West  
Mumbai, Maharashtra 400053, India

**info@caen-india.in**

**www.caen-india.in**

